

**CT36EU PARTS LIST**

<b><u>Ref #</u></b>	<b><u>Part #</u></b>	<b><u>Description</u></b>
1	806315	Glass Ceran Assy With Keypad
2	801351	Screw, 6 x3/8"
3	807073	Board, Control, 36"
4	803143	Cable, Ribbon, 36"
5	802613	Light, Indicator
6	801864	Element Assy., Triple, 2700 Watt, 36"
7	801861	Element Assy., Single, 1500 Watt, 30", 36"
8	801863	Element Assy., Double, 2200 Watt, 30", 36"
9	801860	Element Assy., Single, 1200 Watt, 30", 36"
10	801862	Element Assy., Single, 1800 Watt, 36"
11	800430	Box, Burner, Inner, Insulation, 36"
12	806717	Box, Burner, Inner Assy., 36"
13	807072	Board, Relay, 36"
14	800414	Blower, Transverse
15	806715	Box, Burner, Outer Assy., 36"
16	802668	Guard, Fan
17	802669	Retainer, Fan, Rivet
18	800511	Element, Spring
19	806022	Power Board Mtg Bracket 36
20	806023	Cooktop Fan Mounting Bracket
21	800413	Power Conduit
22	806655	Moisture Barrier, CT36E

**Not Shown**

<b><u>Part #</u></b>	<b><u>Description</u></b>
806299	Unframed Cooktop Installation Pkg.
800419	Terminal Block
801046	Scraper, Cooktop
801048	Gasket, Rubber, Cooktop Surround
801101	Cleaning Cream
800909	Harness, Element, 36"
802709	Hold Down Clamp Kit
802666	Harness, Fan, 36"
800910	Harness, Power, Inlet, 36"
802772	Grommet, Edge

**CT36EU PARTS LIST**

