

15" ELECTRIC FRYER COOKTOP PARTS LIST

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	802547	Box, Fryer Front
2	813360	Transformer, Module
3	808414	Harness, Module Power Supply w/Terminal Block
	813363	Harness, Module Power Supply (w/Terminal Box) *ICB
4	801392	Valve, Manual Shut Off
5	800906	Screw, 6-32 x 1/2" w/Lockwasher
6	802577	Thermodisc, Fryer 350f
7	730239	Screw, #8 X 3/8" Mod. Truss Hd
8	801380	Box, Fryer Burner
	813367	Box, Fryer Burner *ICB
9	800418	#8-32 Hex Nut W/Lock Washer
10	807502	RTD Module Main Temp
11	801542	Screw, 8-18 x 3/8" Type B H/W/Hd
12	804222	Triac, Steamer/Fryer/Grill
13	804409	Baffle, Steamer/Fryer Heat
	813362	Baffle, Steamer/Fryer Heat *ICB
14	802546	Insulation, Steamer/Fryer
15	801401	Basket, Wire Fryer Large
16	801400	Basket, Wire Fryer Small
17	802550	Insulation, Module Element
18	801877	Plate, Element Backing
19	806136	Insulation, Steamer/Fryer Heater
20	810000	Element, Steamer/Fryer
21	805041	Pan, Weld Assy Fryer
22	804220	Bracket, Steamer/Fryer, Rear
23	801878	Fryer Lid, Module
24	801384	Handle, Module Cover
25	804205	Hanger, Fryer Basket
26	802580	Glass, Fryer Assy
27	809536	Control Assy, Fryer
	813368	Control Assy, Fryer *ICB
28	800246	Washer, Teflon .06 x .26 x .5"
29	801883	RTD, Module Fill Sensor
30	808414	Harness, Module Power Supply
31	808415	Harness, Module Cover
32	808412	Harness, Steamer Element
	813369	Harness, Steamer Element *ICB
33	804743	Power Cord Conduit, Module
34	806003	1/4" - 20 Keps Nut SS, RTD

Not Shown

804555 Hold Down Clamp Hdw, Module

15" ELECTRIC FRYER COOKTOP EXPLODED VIEW

