

**WWD30 PARTS LIST**

<u>Ref #</u>	<u>Part #</u>	<u>Description</u>
1	809014	Heating Element
	809170	Heating Element, 240V (International Only)
2	807892	Bracket, Mount, Element
3	809009	Outer Back Panel Assy.
4	809513	Power Cord w/Strain Relief
5	807137	Power Board
	807138	Power Board, 240V (International Only)
6	807882	Bracket, Fan Mount w/Grommets
7	808125	Thermal Cut-Out
8	808129	Grommet
9	806870	Fan
10	809512	Inner Back Panel
11	809008	Baffle, Cavity
12	809409	Bracket, Slide (Left & Right)
13	809406	Slide, Drawer Assy., Left & Right
14	808993	Bracket, Slide, Center
15	808207	Slide, Drawer Assy., Bottom
16	808538	Svce, Seals - WWD30
17	810458	Front Frame, Standard
	808385	Front Frame, Trimless
18	811709	Control Board w/Keypad
	811710	Control Board w/Keypad (International Only)
19	809411	Pan, Inner, SS
20	809013	Communication Cable
21	806871	Thermistor
22	809616	Drawer Assembly, Svce
23	3060130	Switch, Drawer
24	810460	Control Board Bracket
25	810296	Panel, Door Mount
	810459	Panel, Door Mount, Flush (Trimless)
26	810869	SS Front Panel w/Handle
	808465	Plat Front Panel w/Handle
	808464	Carbon Front Panel w/Handle
27	808930	Cable Guard

**Not Shown**

811951	Harness, Main, Frt Cntrl
807198	Harness, Power Board, Rear
808851	Harness, Power Board, Rear (International only)
808126	Clip, Cable Hold Down
808060	Rack, Plate Warmer
808529	Pan Kit, WWD30
808851	Harness, Power Board, Rear (International only)
808853	Transformer (International Only)
808850	Power Cord (International Only)
809314	Connector, Power Cord, Inlet (International Only)

WWD30 EXPLODED VIEW

